# USER MANUAL

►

SoundPlato GD538 Bluetooth Bookshelf Speakers Please read the manual carefully before useand keep it well for further use

SoundPlato

Gladorn®

WARNINGS

This appliance is intended for domestic household use only and should not be used for any other purpose or in any other application, such as for non domestic use or in a commercial environment.

Ventilation

Allow at least a 10 cm gap all around the product.
The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains,
No naked flame sources, such as lighted candles, should be placed on the apparatus. Attention should be drawn to the environmental aspects of battery disposal. Don't throw usedbatteries in dustbin. Please contact your retailer in order to protect the environment.
This apparatus is not suitable for use in a tropical climate. The apparatus shall not be exposed to dripping or splashing and that no objects filledwith liquids, such as vases, shall be placed on the apparatus.To protect the environment, use local recycling facilities for battery disposal.
Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
IMPORTANT SAFETY INSTRUCTIONS
- Keep the unit away from high temperature exposure and high humidity.
- Do not disassemble, modify or attempt to repair the unit.
- Only use the attachments/accessories recommended by the manufacturer.
- Store the unit away from dirt or dust.

### Symbol

CE This mark is applied to show the equipment conforms to European safety and electro-magnetic compatibility standards.

Battery handling and usage
The product is supplied with one rechargeableLithium 3.7V 1200mAh battery incorporated in the product which is not accessible and cannot be replaced. Therefore when the product reaches the end of its useful life it must be disposed of at a recycling centre .

PARTS

Front View

Rear View

Top View

1. Indicator light
2. Microphone
3. ➖ Volume down/previous button
4. ➕ Volume up/next button
5. 🎤 Hands-free function/Play/Pause button
6. ON/OFF Switch
7. DC-5V IN   Charging port
8. LINE IN Jack
9. Stand

Accesories

3.5 mm audio cable

Micro USB cable

CHARGING THE SPEAKER

The speaker has a built-in Lithium battery. It is recommended to charge the internal battery for about 2 hours before using thespeaker.

The fully-charged battery can give up to 7-hour playing time at 50% volume depending on genres of music and volume.

1. Connect the micro USB plug end of the supplied cable to the charging port on the back of the speaker. Connect the standard   USB plug end of the cable into the USB port on your computer or other USB charging device. The indicator light will illuminate red.
2. When the indicator light goes out, the battery is fully charged.
3. After charging, remove the micro USB cable.

Low battery warning:

When you hear two beeps at regular intervals, please recharge the speaker.

### PARING WITH A BLUETOOTH-ENABLED DEVICE

1. Turn on the speaker.
   • The speaker will enter Bluetooth modeand the indicator light will flash blue quickly.
2. To pair, go to Bluetooth settings on your Bluetooth enabled device and connect to "Gladorn SoundPlato".
   • Enter "0000" if asked for a passcode.

Mode	Status
Bluetooth pairing	The indicator light will flash blue quickly.
Paired	You will hear jingle sound and the indicator light will flash blue slowly at regular intervals. **NOTE:** Once the Bluetooth device is connected for the first time, the speaker will remember the paired setting and will automatically reconnect to the same Bluetooth device the next time they are in range.

LISTENING TO MUSIC

- Once the speaker has been successfully paired to your music device, you can listen to music by using
- ♫, + and −.
  Adjust the volume as desired by repeatedly pressing + / −.
- Select the desired track to play by pressing and holding + − about seconds.
- To pause, press ♫. To resume play, press ♫ again.

NOTE:
When you want to playback from another Bluetooth device, press ♫ twice to disconnect the speaker by from the Bluetooth device already in use.

HANDS-FREE FUNCTION:
1. To receive an incoming call, press ♫ .
2. To end a call, press ♫ again.

LINE IN

1. Connect the supplied audio cable from an auxiliary audio device to the LINE IN jack of the unit. The indicator light will illuminate blue.
2. Adjust the volume by repeatedly pressing + / −
3. Press 🔇 to mute the music,Press 🔇 once more to listen again .

CLEANING AND MAINTENANCE

Clean the unit with a soft, damp cloth and wipe it with a dry cloth.
Never immerse it in water.Do not use abrasive or chemical cleaning agents.
Store the unit in a cool, dry place, away fromthe dust or dirt.

SPECIFICATIONS

DC input: 5 V ━━ 500mA
Rechargeable battery: 3.7V ━━ 1200mAh
Speaker power (RMS): 3W x 2
Frequency range: 2.402GHz – 2.480GHz
Output power: 4-6dBm

DISPLOSAL

As a responsible company we care about the environment. As such we urge you to follow he correct disposal procedure for the product, packaging materials and if applicable, accessories and batteries. This will help conserve natural resources and ensure that the materials are recycled in a manner that protects health and the environment.

You must follow laws and regulations about disposal. Waste electrical products and batteries must be disposed of separately from household waste when the product reaches the end of its life. Contact the store where you bought the product and your localauthority to learn about disposal and recycling.

The batteries must be disposed of at your local recycling point.

We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.